























































## Feature operation

AutoDial			
Store	AutoDial 		AutoDial 
Use		AutoDial 	
Display	Display 	AutoDial 	
Call Forward			
Activate	Fwd 		Fwd
Deactivate		Fwd	
Reinstate	Fwd 	Fwd	
View number	Display 	Fwd	
Call Pickup		Pickup	
Call Waiting			
Answer		Call Waiting	
	(Hold)		
Return to first call			
	(Goodbye)		
Conference	Conf 		Conf
Handsfree			
Activate			(to end the call)
	(Handsfree)	(Goodbye)	
Switch to handset			
Handset to handsfree			
	(Handsfree)		
Activate Headset			(to end the call)
	(Headset)	(Goodbye)	
Hold			
Place a call on hold			
	(Hold)		
Return to a held call			
Last Number Redial			
Message			(Msg/Inbox)
Ring Again			
Activate	RngAgn 		
When notified		RngAgn	
Deactivate		RngAgn	
Transfer	Trans 		Trans
Adjust volume		or 	(Volume -)
	(Volume +)		

## Legend

Icon	Action
( )	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the <b>Headset</b> key.
	Replace the handset, or press  to end the call.

## Legend (continued)

Icon	Action
	Press a line/feature key.
	Dial a number.
	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
	Press the <b>Services</b> key once for Call Platform features, or press the <b>Services</b> key twice for local phone features.
	Press the <b>Message/Inbox</b> key.
	Press the <b>Up/Down Navigation</b> keys
	Press the <b>Enter</b> key
	Press the <b>Headset</b> key.
	Press the <b>Handsfree</b> key.
	Press the <b>Mute</b> (on/off) key.
	Press the <b>Directory</b> key.
	Press the <b>Quit/Stop</b> key.

## Services and Telephone Options menus

### Services menu



**Note:** The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1120E phones. Consult your system administrator.

The following are the most commonly used options:

### Telephone Options menu

#### Volume adjustment

Pick one of:



#### Contrast adjustment



#### Language



**Note:** This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.

#### Date/Time format



#### Local DialPad Tone



#### Ring type



#### OnHook default path



**Note:** The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide* (NN43112-103).

## Nortel IP Phone 1120E



\*Note: If supported by your server, the data message waiting indicator provides a data alert. Contact your system administrator to find out if this feature is available for you.

# NORTEL

[www.nortel.com](http://www.nortel.com)

## IP Phone 1120E

For Nortel Communication Server 1000

## Quick Reference Card



Date: May 2007

Document Release: Standard 01.01

Document Number: NN43112-106

Copyright © 2006–2007 Nortel Networks.

All Rights Reserved.

\* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.