Standard VNMRJ commands and parameters to acquire, process and print out the 1D NMR spectra (^{1}H, ^{19}F, ^{13}C, ^{31}P, ^{11}B etc)

aa—abort acquisition
ai—absolute intensity mode
aph—automatic phase correction
at—acquisition time (sec)
axis—scale units: axis='h' or axis='p'
bc—baseline correction
bs—block size
cz—clear zeros (integral)
d1—first delay (relaxation delay)
dc—drift correction
df—display fid
dg—display group of parameters
dli—display integral list
dll—display line list
dlni—display normalized integral list
dpf—display peak frequencies
dpir—display integral regions
dpirn—display normalized integral regions
res—digital resolution
ds—display spectrum
dscale—display scale
dssa—display stacked spectra
dssh—display stacked spectra horizontally
f—display full spectrum
fn—Fourier number (zerofill)
full—display spectrum in full window
ga—acquire and process
gain—receiver gain: gain='n' for autogain
go—acquire spectrum
ho—horizontal offset
ins—integral normalization scale
io—integral offset
isadj—adjust integral scaling
jexp—join experiment: jexp2
lb—line broadening
lp—left phase
movesw—move sweepwidth
mp—move parameters: mp(1,2)
nl—nearest line
nm—normalized mode
np—number of points
nt—number of transients (scans)
pad—preacquisition delay
page—send to plotter
pap—plot all parameters
pir—plot integral regions
pirn—plot normalized integral regions
pl—plot spectrum
printon dli printoff —print integral values (tabulated)
pll—print line list
plot—plot everything
ppa—plot partial parameters
ppf—plot peak frequencies
pscale—plot scale
pw—pulse width
ra—resume acquisition (stopped by sa)
rl—reference line: rl(7.27p)
rtp—retrieve parameters
rts—retrieve shims
sa—stop acquisition
sc—start of chart (in mm)
sd—set decoupler
sfrq—spectrometer frequency
sp—start of chart (in ppm)
ss—steady state scans
su—setup hardware parameters
svf—save FID
svs—save shims only
svp—save parameters only
sw—spectral width or sweep width
temp—set temperature: temp='n'
tn—transmitter nucleus
tof—transmitter offset (middle of sweepwidth)
tpwr—transmitter power
unlock—unlock a locked experiment: unlock(2)
vo—vertical offset
vp—vertical position
vs—vertical scale
vsadj—vertical scale adjust
wc—width of chart (in mm)
wp—width of chart (in ppm)
wft—weighted Fourier transform
z—cut integral reset